

A700182-GBG1 or A711007-GBG1 (B3300) Fill Valve Adjustment:



How to lock/unlock Fill Valve and adjust tank water (Figure 1)



Remove clip (Figure 2)



Turn body counter-clockwise (Figure 3)



Adjust Valve body (Figure 4)

How to Lower or raise the water level setting of the fill valve?

1. Remove the gray clip by pulling it down (Figure 2).
2. Turn Fill valve body counter-clockwise 1/8 turn to unlock it (Figure 3).
3. Pull bottom shank away from valve body to raise water level in the tank or push it to the valve body to shorten it to lower tank water level (Figure 4).
4. Then Turn Valve body clockwise to lock it and push the gray clip back in place.