

Toilet Seat (Style C):

Seat Contents:

1. EZ Clean Seat Cover
2. Seat Hinge
3. Hinge Covers
4. Hinge Friction Pads
5. Bolts
6. Plastic Anchors



Suggested Installation Steps:

1. Place the plastic anchors (6) into the seat holes located on the rim of the bowl



2. Firmly push the anchor (6) into the seat hole so that the top of the anchor is flush with the rim of the bowl



3. Insert the clear hinge friction pad (4) into the base of the seat's hinge (2).



4. Place the seat hinge (2) over the plastic anchor (6) loosely so that the slot is positioned over the anchor's bolt opening



5. Insert the metal bolt (5) through the hinge (2) and into the anchor (6) and loosely tighten the bolt. NOTE: Do not over tighten bolts, ensure seat hinge is loose for adjustment purposes.



6. Insert the EZ Clean Seat cover (1) onto the hinge's(2) posts. NOTE: Slight hinge adjustment may be required.



7. Adjust the seat cover (1) so that it fits about the contours of the rim. NOTE: May have to adjust the seat hinges to ensure satisfactory fit.



8. Once the seat cover (1) is fitted, hold the seat cover firmly in desired position and firmly tighten the seat bolts (5) to secure the hinge (2) to the rim.



9. Once the bolts (5) are firmly tightened, release the seat cover (1) utilizing its integrated release mechanism in order to validate ease of seat removal and consequently reassembly **(there is a button on each side between the seat and seat lid as indicated below by the red arrows, that you can pull to the centre of the seat to release it)**. NOTE: Seat hinge may require further adjustment to ensure ease of seat removal.



10. Once the seat hinges (2) are in a satisfactory position and secured to the rim of the bowl, insert the plastic hinge covers (3) over the hinge.



11. Insert the seat cover (1) onto the hinge posts.

